

HA18PX

Maintenance Book

HA18PX

4001022490

E 02.19

USA / GB



A**Preface -
Foreword**

1 - Symbols and colors	8
-------------------------------------	----------

B**Safety**

1 - General safety rules	11
---------------------------------------	-----------

1.1- Maintenance implementation.....	11
1.2- Uncontrolled movement Hazard.....	12
1.3- Electrocution Hazards	12
1.4- Explosion / Fire Hazards	13

2 - Maintenance and repair training	14
--	-----------

2.1- Owner's responsibility	14
2.2- Technician's responsibility	14
2.3- HAULOTTE Services®.....	14
2.4- Training	14
2.5- Product modification	15
2.6- After Sales Service	15
2.7- Product information.....	15

3 - Manufacturer's warranty	16
--	-----------

3.1- Warranty acceptance.....	16
3.2- Warranty period.....	16
3.3- Conditions of warranty	16
3.4- Warranty conditions	17

CONTENTS

C**Familiarization**

1 - Primary machine components	20
1.1- Layout	20
1.2- Ground control box	22
1.2.1 - Layout	22
1.3- Platform control box	24
1.3.1 - Layout	24
2 - List of actuators and sensors	26
2.1- Sensors and actuators	26
3 - Power source - Engine specifications	27
3.1- General safety and specific interventions on motor	27
3.2- General Specifications	27
3.3- Consumables	28
3.4- Ingredient	28
4 - Lubrication diagram	30
5 - Consumables (Oils - Fuels - Engine oil - Coolant level...)	32
5.1- Fuel	32
5.1.1 - Other fuels	33
5.2- Engine oil	34
5.3- Hydraulic oil	35
6 - Machine specifications	36
6.1- Movement speed	36

D**Inspection and maintenance schedule**

1 - Inspection program	37
2 - Daily inspection	38
3 - Preventive maintenance	38
4 - Periodic inspection	43
5 - Major inspection	45



Machine sheet

MS0001 - Structural part inspection	47
E002 - Wheel reducer	51
MS0002 - Pins and bearing inspection	53
MS0003 - Cylinder inspection	57
E004 - Fuel tank	61
MS0004 - Braking test procedure	63
E005 - Slew ring	65
MS0005 - Torque Values	69
E006 - Wheel	71
E007 - Screws, bolts and nuts	75
E013 - Pulleys and wear pads	77
E018 - Battery	79
MS0021 - Hydraulic filter cartridge Replacement	83
E030 - Glow plugs	87
MS0133 - Universal plug	89

CONTENTS



E**Trouble shooting and diagram**

1 - Trouble shooting	91
1.1- Recommendations.....	91
1.2- Description	91
2 - Troubleshooting	92
3 - Legend	94
3.1- Electric circuit	94
3.1.1 - Main components	94
3.1.2 - Fuses	98
3.1.3 - Relays and terminals	100
3.1.4 - Connectors	102
3.1.5 - Diagnosis assistance indicators	104
3.1.6 - Buzzers	105
3.1.7 - Indicators	105
3.2- Hydraulic circuit	106
3.2.1 - Solenoid valves	106
3.2.1.1 - Drive unit	107
3.2.1.2 - Steering unit	109
3.2.1.3 - Unit TOR	110
3.2.1.4 - Proportional unit	111
4 - Electric diagram	114
5 - Hydraulic diagram	124

F**Records**

1 - Intervention register	127
--	------------



A-Preface - Foreword

You have just purchased a HAULOTTE® product and we would like to thank you for your business.

The Aerial Work Platform is a mechanical device primarily designed and manufactured with the intent to position people with the necessary tools and material to overhead elevated temporary workplaces. All other uses or alterations/modifications to the aerial work platform must be approved by HAULOTTE®.

This manual shall be considered a permanent component of the machine and shall be kept with the aerial work platform in the designated Manual Holder, at all times.

Safe operation of this product can only be assured if you follow the operating instructions contained in this manual are followed. To ensure proper and safe use of this equipment, it is strongly recommended that only trained and authorized personnel operate and maintain the aerial work platform.

We would particularly like to draw your attention to 2 essential points :

- Compliance with safety instruction (machine, use, environment).
- Use of the equipment within the performance limits.

With regard to the designation of our equipment, we stress that this is purely for commercial purposes and not to be confused with the technical specifications. Only the specifications in this manual should be used to study the suitability of the equipment for the intended use.

This maintenance and repairs book is specific to the HAULOTTE® products listed on the cover page of this manual. The maintenance book is intended for the on-site maintenance technician.

It is the on-site maintenance technician's duty to carry out the regular maintenance work recommended by HAULOTTE Services®.

This maintenance work is essential for correct machine operation.

If regular maintenance is not carried out, this may :

- Void the warranty.
- Cause machine malfunction.
- Reduce machine reliability and shorten its service life.
- Jeopardize operator safety.

To ensure that the regular maintenance requirements are fully satisfied, contact HAULOTTE Services®.

HAULOTTE Services® technicians are specially trained to carry out extensive repairs, interventions or adjustments on the safety systems or elements of HAULOTTE® machines. They carry genuine HAULOTTE spare parts and tools as required, and also provide fully documented reports on all work completed.












A-Preface - Foreword

1 - Symbols and colors

Symbols and colors are used to alert the operator of safety precautions and/or to highlight important safety information.











The following safety symbols are used throughout this manual to indicate specific hazards and the hazard severity level when operating or maintaining the Aerial Work Platform.

Symbol

Symbol	Description
	Danger : Risk of injury or death
	Caution : Risk of material damage
	Prohibition relating to work safety and quality
	Reminder to use good practice or follow pre-operation checks
	Cross-reference to another part of the manual
	Cross-reference to another manual
	Cross-reference to repair (contact HAULOTTE Services®)
	Maintenance sheet
	Recommended tools
	Recommended part
	Safety
N.B. :	Additional technical information

A-Preface - Foreword

Decals

Color	Title	Description
		Danger : Indicates a hazardous situation which if not avoided, WILL result in death or serious injury.
		Warning : Indicates a hazardous situation which if not avoided, COULD result in death or serious injury.
		Caution : Failure to comply could result in minor or moderate injury.
		Notice : Indicates practices not related to personal injury.
		Procedure : Indicates a maintenance operation.

N.B.:-THE FOLLOWING SAFETY ADVISORIES ARE USED THROUGHOUT THIS MANUAL TO INDICATE SPECIFIC HAZARDS WHEN OPERATING OR MAINTAINING THE TELEHANDLER.

1 - General safety rules


1.1 - MAINTENANCE IMPLEMENTATION

Your safety and the safety of the people around are essential.

Make sure the work area is clean in order to not to pollute the system of the machine.

Before performing any maintenance interventions, place the machine in maintenance configuration.

1. Place the machine on firm, level ground.
2. Stow the machine completely.
3. Push the E-stop button to cut off the electricity supply.
4. Insert the turntable rotation locking pin.



Never leave the hydraulic cylinders fully extended before switching off the machine, or when stationary for an extended period of time. Keep the elements of the machine in configuration of maintenance thanks to mechanics devices.

Report that the machine is under maintenance by tagging the platform and ground control boxes.

Note :

- Using the machine during maintenance is strictly forbidden.
- Do not climb onto the covers.
- The handling of parts must be carried out using appropriate equipment (Chains, Lifting slings, Lifting anchors).
- Plug the end of any hoses removed, and cap any open ports to prevent contamination during maintenance.

B-Safety

1.2 - UNCONTROLLED MOVEMENT HAZARD

Be aware of uncontrolled movement and always respect the following :

- Maintain clearance from high voltage lines.
- Maintain clearance from generators, radar, electromagnetic fields.
- Never expose the batteries or electrical components to water (high pressure washer, rain).
- Never tow the machine over extended distances.
- In case of a machine breakdown, it is possible to tow short distance to load it onto a trailer.
- Never leave the hydraulic cylinders fully extended before switching off the machine, or when stationary for an extended period of time.
- Retract and lower the boom to the stowed position rotate the turntable so that the boom is between the non-steering wheels.
- Select a safe parking location, on a firm level surface, clear of obstruction and traffic.
- Ensure all compartments are closed and secured.
- Chock the wheels.

1.3 - ELECTROCUTION HAZARDS

The machine is not electrically insulated and does not provide protection from contact or proximity to electrically charged conductors.

Always position the lift at a safe distance from electrically charged conductors to ensure that no part of the machine is within an unsafe area.

Respect the local rules and the minimum safety distance from power lines.

Minimum safe approach distances

Electric voltage	Minimum safety distance	
	Mètre	Feet
0 - 300 V	Avoid contact	
300 V - 50 kV	3	10
50 - 200 kV	5	15
200 - 350 kV	6	20
350 - 500 kV	8	25
500 - 750 kV	11	35
750 - 1000 kV	14	45

N.B.-:-THIS TABLE IS APPLICABLE, EXCEPT WHEN THE LOCAL REGULATIONS ARE MORE STRICT.

B-Safety

Do not operate the machine :

- Do not operate the machine when close to live power lines, consider the movement of the machine and the sway of the electric power lines particularly in windy conditions.
- Do not operate the machine during lightning, thunderstorms, snow/ice or any weather condition that could compromise operator safety.
- Do not operate the machine during lightning or storms.
- Do not use the machine as a welding earth.
- Do not wash electrical components with a high pressure washer.
- Do not weld on the machine without first disconnecting the battery terminals.
- The machine must not be used while charging the batteries.
- When using the platform AC power line, ensure it is protected with a circuit breaker.



Keep away from the machine if it contacts energized power lines. Personnel on the ground or in the platform must not touch or operate the machine until energized power lines are shut off.

In the event of accidental contact with a high voltage line, wait for the power to the line be de-energized before attempting to operate the machine.

1.4 - EXPLOSION / FIRE HAZARDS

Always wear protective clothing and eye wear when working with batteries and power sources/systems.

N.B.-:-ACID IS NEUTRALIZED WITH SODIUM BICARBONATE AND WATER.

- Do not start the engine if you smell or detect liquid propane gas (LPG), gasoline, diesel fuel or other explosive substances.
- Do not work in an explosive or flammable atmosphere / environment.
- Do not touch hot components.
- Do not bridge the battery terminals with metallic objects.
- Do not service the battery in proximity of spark, open flame, lit cigarettes.
- Do not fill up the fuel tank, when the engine is running and/or near a flame.



2 - Maintenance and repair training

2.1 - OWNER'S RESPONSABILITY

The owner (or hirer) has the obligation to inform technician of the instructions contained in the Operator Manual and Maintenance Book.

The owner (or hirer) has the obligation to renew all manuals or decals that are either missing or in bad condition.

Additional copies can be ordered from HAULOTTE Services®.

The owner (or hirer) is responsible for applying the local regulations regarding maintenance of the machine.

2.2 - TECHNICIAN'S RESPONSABILITY

The technician must read and understand the contents of this manual, operators manuals and the decals affixed on the machine.

The technician must inform the owner (or hirer) if the manual or any decals are missing or in poor condition, and of any malfunction of the machine.



Only authorized and qualified operators may operate HAULOTTE® machines.

2.3 - HAULOTTE SERVICES®

The HAULOTTE® is at your service in all 5 continents of the world via an extensive network of its own factory trained technicians, who are ready to respond to your every need.

2.4 - TRAINING

Whether you want to just service your equipment or carry out a complete overhaul, HAULOTTE® can provide you with a structured training program or we can tailor a program to suit your specific requirements or circumstances. Training can cover the general operation of the equipment, breakdowns, engine maintenance and repairs and electrical/hydraulic/mechanical repairs and trouble shooting.

2.5 - PRODUCT MODIFICATION

In a constant effort to improve the quality of machines, HAULOTTE continually monitors technical improvements that enable to develop products with improved safety and greater reliability. The target being that HAULOTTE® always work to build confidence in the relationships with our customers.

These improvements will be shared via the following documents :

- OI : Obligatory Intervention, Safety information requiring immediate action (take into account by HAULOTTE®).
- NI : Technical improvement requiring immediate action (take into account by HAULOTTE®).
- RI : Improvement proposed to customers to take into account during maintenance operation.
- PI : Product information for knowledge.

2.6 - AFTER SALES SERVICE

Our HAULOTTE Services® After Sales Service is at your disposal throughout your machine's service life to ensure the optimum use of your HAULOTTE product :

- When contacting our After Sales Service, ensure that you provide the machine model and serial number.
- When ordering any consumables or spare parts, please use this manual and the HAULOTTE® Essential catalogue to receive your genuine HAULOTTE® spare parts, your only guarantee of parts interchangeability and correct machine operation.
- If there is an equipment malfunction involving a HAULOTTE® product, then contact HAULOTTE Services® immediately even if the malfunction does not involve material and/or bodily damage.

2.7 - PRODUCT INFORMATION

Without the written permission from Haulotte, modifying a HAULOTTE® product is a Safety concern. Any modification may violate Haulotte design parameters, government regulations and industry standards.

If you desire a modification to the product, submit a request in writing to HAULOTTE.

With the utmost care to ensure enhanced reliability and greater safety of the HAULOTTE® products, it is pertinent that when a "Service or Safety Bulletin" is issued, action is taken immediately. Once the bulletin has been addressed, make sure that the completed form is submitted to HAULOTTE Services®.

Do not hesitate to contact HAULOTTE Services®, should you have any questions relating to the issued bulletin(s) or with questions on the policy itself.

3 - Manufacturer's warranty

3.1 - WARRANTY ACCEPTANCE

On reception of his machine, the owner or rental company must check the machine's condition and fill out the machine reception slip provided.

3.2 - WARRANTY PERIOD

The present warranty is valid for a period of 12 months or up to a maximum of 1000 operating hours for personnel lifting machines and 12 months or up to a maximum of 1500 operating hours for the other machines, including MJX or the Telescopic Handlers, starting from delivery and terminating when the first limit is reached.

Spare parts are covered by a 6 month warranty.

3.3 - CONDITIONS OF WARRANTY

HAULOTTE® guarantees its products against defects, faults or manufacturing defects when the owner or rental company has informed HAULOTTE® of the defect.

The warranty does not cover the consequences of normal wear, nor any defects, failure or damage resulting from poor maintenance or abnormal usage, in particular overloading, impact by an external source, faulty installation or any modification made to products marketed by HAULOTTE® and performed by the owner or rental company.

In the event of operation or use which does not comply with the instructions or recommendations in the maintenance book, warranty claims will not be accepted.

The machine utilisation period must be recorded by reading the engine hour meter whenever an intervention is made. The engine hour meter must be maintained in good working order to guarantee maximum working life and to justify maintenance at the recommended time.

Warranty obligations for the time period stated above will cease immediately in situations where the defect is due to the following reasons :

- Use of spare parts that are not HAULOTTE® originals.
- If elements or products other than those recommended by the manufacturer are used.
- If the HAULOTTE® name, serial numbers or identification marks are removed or altered.
- After an unreasonably long delay before reporting a manufacturing problem.
- If the owner or rental company continues to use the machine despite problems.
- If damage is caused by modifications that do not comply with HAULOTTE® specifications.
- If lubricants, hydraulic oils or fuels that do not comply with HAULOTTE® recommendations are used.
- If the machine is incorrectly repaired or used by the customer.

If no particular agreement has been made, any claims made after the previously established warranty period has expired will be refused.

The present warranty does not cover damage that may result directly or indirectly from any flaws or defects covered by the latter :

- Consumables : No claims will be accepted for objects or parts replaced in the context of normal machine usage.
- Settings : Adjustments of all sorts may become necessary at any time. Therefore adjustments are considered a part of normal machine usage conditions and are not covered by the warranty.
- Hydraulic and fuel circuit contamination : Every possible precaution is taken to ensure that fuel and hydraulic liquid delivered is clean. On the other hand, in certain cases it is possible to contaminate fuel and hydraulic circuits, especially when fuel and lubricants are stored on the work site. Moreover, irregular or poor cleaning of the decanting device may also cause fuel/hydraulic circuit contamination and therefore damage the parts in direct contact with these liquids. HAULOTTE® will not accept any claims concerning cleaning of the fuel circuit, filter, injection pump or any other equipment in direct contact with fuel or lubricants.
- Wearing parts (pads, bearings, tires/tyres, connections, etc.) : These parts are, by definition, subject to deterioration during the period of operation. Wearing parts will therefore not be covered by the warranty agreement.

3.4 - WARRANTY CONDITIONS

To benefit from the warranty, the owner or rental company must inform the nearest HAULOTTE® subsidiary or the subsidiary that delivered the machine (the only dealer authorised to carry out an intervention under the manufacturer's warranty agreement) of the defect in writing as quickly as possible.

The subsidiary will decide whether to repair or replace the part that proves to be faulty.

The owner or rental company must present the duly completed maintenance book supplied with the machine as proof that the maintenance operations recommended by the manufacturer have been carried out.

The owner or rental company must ensure that the defect covered by the HAULOTTE® warranty is reported to and acknowledged by the HAULOTTE® subsidiary the only dealer authorised to carry out work covered by the warranty) as rapidly as possible or must report the defect in writing.


Work carried out under the HAULOTTE® warranty will be performed by the subsidiary which delivered the machine, wherever possible.

C-Familiarization

1 - Primary machine components

1.1 - LAYOUT

HA18PX - HA51JRT



C-Familiarization

Marking	Description	Marking	Description
C1	Chassis	C27	Ground control box + Universal plug
C2	Front driven steering axle	C28	Tilt sensor
C3	Rear drive and/or steer wheel	C30	Hydraulic oil tank
C4	Jib	C31	Fuel tank
C5	Platform support with load limiter	C32	Turntable rotation gearbox
C6	Platform	C33	Counterweight
C7	Platform control box	C34	Drive wheels
C8	Input jib leveling cylinder	C35	Document holder
C9	Upper boom (or boom tube)	C36	Top arm
C10	Slew ring	C37	Operating batteries
C11	Turntable assembly	C38	Bottom arm
C12	Side cover	C39	Top tie rod
C13	Arm/Boom link piece	C41	Bottom tie rod
C14	Hydraulic drive motor and reducer	C42	Foot Switch
C20	Tie-down (and/or lifting) points	C43	Turntable rotation lock pin
C22	Boom lift cylinder	C140	Propane bottles - (For ANSI / CSA standard only)
C26	Engine and hydraulic pump	C154	For Russia and the Ukraine only : Temperature probe relays

Universal plug




C-Familiarization

1.2 - GROUND CONTROL BOX

1.2.1 - Layout

General view



C-Familiarization

Controls and indicators


Marking	Description	Function
2	Engine oil pressure light	Low engine oil pressure
3	Engine temperature indicator	High engine oil temperature
4	Battery charging indicator	Low battery charge
5	Air filter clogging indicator	Clogged air filter
6	Platform overload indicator	Platform overload
8	Jib lifting / lowering switch	Move upwards : Jib lifting Move downwards : Jib lowering
9	Boom telescoping switch	Move to the left : To extend the boom out Move to the right : To retract the boom in
10	Boom raising switch	Move upwards : Boom raising Move downwards : Boom lowering
12	Arm lifting selector	Move upwards : Arm raises Move downwards : Arm lowers
13	Platform levelling	Move to the right : Platform leveling lowered or placed in transport position Move to the left : Platform leveling raised or placed in operating position
14	Turntable rotation switch	Move to the left : Counter clockwise (CCW) rotation Move to the right : Clockwise (CW) rotation
15	E-stop button	Pulled out : Ground control box energized Pushed in : De-energizes control system
20	Hour meter	Total machine running hours
21	Engine revs selector	Move to the right : Engine speed increases Move to the left : Engine idle speed
22	Engine start-up selector	Starting the engine
24	Beacon light on/off	Move to the right : Beacon light on Move to the left : Beacon light off
72	Control box activation key switch	Left : Platform control box energized Center : De-energizes control system Right : Ground control box energized
228	Enable Switch / Back-up unit selector	Move upwards : Engine start Move downwards : Enable switch. If the engine is switched off, the emergency electropump is engaged automatically.
245	"Overriding system" switch under cover	Emergency lowering system enabled when the cover is lifted. This must be used ONLY when normal operation from the ground box is unavailable - use in emergencies ONLY.

C-Familiarization

1.3 - PLATFORM CONTROL BOX

1.3.1 - Layout




General view



Controls and indicators

Marking	Description	Function
26	Fault indicator	Operation malfunction Machine on excessive slope
30	Platform overload indicator	Platform overload
31	Power ON indicator	On : Machine switched on Off : Machine switched off
33	Drive joystick	Move forward : Forward drive Move backwards : Reverse drive
	Front axle steering selector	Press right side of button : Right-hand steering Press left side of button : Left-hand steering
34	Rear axle steering selector	Move to the right : Right-hand steering Move to the left : Left-hand steering
35	Differential lock selector	Toggle and hold (activated) : Maximum drive torque (on difficult or sloping ground) Release (deactivated) : Standard torque
37	Jib lifting / lowering switch	Move forward : Jib lifting Move backwards : Jib lowering
38	Platform rotation switch	Move to the right : Counter clockwise (CCW) rotation Move to the left : Clockwise (CW) rotation

C-Familiarization

Marking	Description	Function
40	Platform leveling switch	Move forward : Raise platform
		Move backwards : Platform lowers
41	Back-up unit selector	Toggle and hold : Back-up unit activated
		Release : Back-up unit deactivated
42	Engine start-up selector	Starting the engine
43	Horn button	Horn
44	Petrol/Liquid propane gas selector ¹	LPG : Propane Gas supply
		G : Petrol/Liquid propane gas or diesel supply
46	E-stop button	Pulled out : Ground control box energized
		Pushed in : De-energizes control system
49	Turntable rotation joystick	Move to the right : Counter clockwise (CCW) rotation
		Move to the left : Clockwise (CW) rotation
	Boom lift joystick	Move forward : Boom raising
		Move backwards : Boom lowering
50	Arm raising/lowering joystick	Move forward : Arm raises
		Move backwards : Arm lowers
51	Electric pre-heating indicator	On : Engine in pre-heating mode
		Off : Engine pre-heated, starting possible
54	Boom telescoping switch	Move to the right : To retract the boom in
		Move to the left : To extend the boom out
71	Drive speed selector	 High-speed drive
		 Medium-speed drive (difficult ground, slope)
		 Low-speed drive


1. For machines fitted with

C-Familiarization

2 - List of actuators and sensors

2.1 - SENSORS AND ACTUATORS

Sensors and actuators



Marking	Description
SQ1	Tilt sensor
SQ2	Jib movements cut-off
SQ3	Boom movements cut-off
SQ4	Arm movements cut-off
SQ5 - SQ6	Overloaded platform position sensor
SQ20	Right-hand rotation cut-off
SQ21	Left-hand rotation cut-off

C-Familiarization

3 - Power source - Engine specifications

3.1 - GENERAL SAFETY AND SPECIFIC INTERVENTIONS ON MOTOR

The technician should take all steps to protect themselves or others against all risks of injury inherent in his intervention.

The technician should ensure that suitable PPE (personal protective equipment) for the job is used, and check the particular conditions of environment in which the material can be found (see safety information specific to the operation site).

- Turn off the ignition, remove the key, open the battery switch before working on the engine.
- Accidental engine starting can cause injury or death to personnel working on the equipment. To avoid accidental engine starting, disconnect the battery cable from the negative (-) battery terminal. Completely tape all metal surfaces of the disconnected battery cable end in order to prevent contact with other metal surfaces which could activate the engine electrical system. Place a do not operate tag at the start/stop switch location to inform personnel that the equipment is being worked on.
- The hot engine parts can cause injury and burns. Before performing maintenance on the engine, cool the engine and parts.
- By touching a functioning engine, there is a risk of burns from contact with hot parts, and injuries by the rotating parts.
- To avoid any risk of accident, using compressed air (example : blowing air filter), always wear a headband and goggles.
- The hot coolant, steam and alkalis can cause injury. At the operating temperature, the engine coolant is hot and under pressure. Do not open the cap of the expansion chamber before letting the circuit cool.
- The radiator and all the pipes going to the heaters or engine contain hot coolant or steam. Contact can cause severe burns.



The engine exhaust gases contain harmful combustion products. Always start and run the engine in a well ventilated area. In an enclosed area, evacuate the exhaust outside.

3.2 - GENERAL SPECIFICATIONS

N.B.-:USING UNSUITABLE FUEL MAY CAUSE DIMINISHED PERFORMANCE, DIFFICULTIES STARTING, EXCESSIVE POLLUTION AND PREMATURE WEAR. TO ESTABLISHED THE TYPE OF THE FUEL SUITABLE FOR THE ENGINE FITTED ON YOUR HAULOTTE®, PLEASE REFER TO THE ENGINE MANUFACTURER'S MANUAL. THE ENGINE MAY NOT BE COVERED BY THE WARRANTY IN CASE OF DAMAGE CAUSED BY USING UNSUITABLE FUEL.

C-Familiarization

3.3 - CONSUMABLES

List of consumables


Consumable	HAULOTTE® code
Hydraulic filter cartridge	2427002910
Air filter (system)	2427003170
Diesel pre-filter	2324000620
Diesel filter	2427003150
Engine oil filter	2324000610

3.4 - INGREDIENT

Ingredient	HAULOTTE® code
Coolant	2326013640
Engine oil	2820305720
Hydraulic oil - Standard	2505003800
Hydraulic oil for hot countries (Option)	2505003820
Hydraulic oil - Driving reducer	2505004030







C-Familiarization

4 - Lubrication diagram



C-Familiarization

List of ingredients

Marking	Ingredient	Symbol	HAULOTTE® code
1	Engine oil - Barrel 209 l(55,2 gal US)		2820305720
2	Gear box oil - Barrel 209 l(55,2 gal US)		2505004030
3	Hydraulic oil (Standard) - Barrel 209 l(55,2 gal US)		2505003800
	Hydraulic oil for hot countries (Option)		2505003820
4	Biological hydraulic oil - Barrel 209 l(55,2 gal US)		2505003830
5	Extreme-pressure lithium grease		4000049970





























C-Familiarization

5 - Consumables (Oils - Fuels - Engine oil - Coolant level...)

5.1 - FUEL

N.B.--THESE FUELS CAN BE USED ON ANY TYPE OF MECHANICAL INJECTION ENGINE. PLEASE SEE MACHINE CONFIGURATION.

Table of technically permitted fuels

Engines Hydraulic filter cartridge	Fuels			
	European gas oil according to EN590	European fuel oil according to BS2869 class 2	American gas oil according to ASTMD975-07b	Japanese gas oil according to NATO F54
HATZ 41C				
DEUTZ 2011/2012				
PERKINS 403/804/ 1104				
LOMBARDINI LDW 1404				
KUBOTA D1105-W1				
KUBOTA V2403				
KUBOTA V2703				

Compliant



Not compliant



C-Familiarization

5.1.1 - Other fuels

- Biofuels : According to EN14214 (EU) and ASTM D6751-07a (USA) biofuels are allowed on some engines and under certain conditions. For more information, please contact HAULOTTE Services®.
- Jet engine fuels (kerosene) : F34 and F35 types under OTAN designation are possible on some engines and under certain conditions. For more information, please contact HAULOTTE Services®.
- The use of vegetable oils is forbidden.

C-Familiarization

5.2 - ENGINE OIL

The correct SAE viscosity grade of oil is determined by the minimum ambient temperature during cold engine start-up, and the maximum ambient temperature during engine operation.

Refer to Table "Engine Oil Viscosity" (minimum temperature) in order to determine the required oil viscosity for starting a cold engine.

Refer to Table "Engine oil Viscosity" (maximum temperature) in order to select the oil viscosity for engine operation at the highest ambient temperature that is anticipated.

Generally, use the highest viscosity oil that is available to meet the requirement for the temperature at start-up.

Engine oil viscosity

EMA LGR-1 / API CH-4 Viscosity grade	Ambient temperature	
	Minimum	Maximum
SAE 0W20	-40°C (-40°F)	10°C (50°F)
SAE 0W30	-40°C (-40°F)	30°C (86°F)
SAE 0W40	-40°C (-40°F)	40°C (104°F)
SAE 5W30	-30°C (-22°F)	30°C (86°F)
SAE 5W40	-30°C (-22°F)	40°C (104°F)
SAE 10W30	-20°C (-4°F)	40°C (104°F)
SAE 15W40	-10°C (14°F)	50°C (122°F)

Engine sump

Engine Refill Capacities	
Compartment or System	Liters
Engine only	9,5 L (2,51 Imp. gal)

(1) The external system includes a radiator or an expansion tank with the following components : heat exchanger and piping. Refer to the QEM specifications. Enter the value for the capacity of the external system in this row.

Classification API

Fuel type	Engine oil classification
	Engines with non EGR Engines with internal EGR
High sulfur fuel ≤ [0.05% (500 ppm)] Sulfur content < 0.50% (5000 ppm)	CF (If the engine oil is used with a high sulfur level, change the engine oil at shorter intervals, approximately half)
EGR : Exhaust Gas Re-circulation	

C-Familiarization

5.3 - HYDRAULIC OIL

Hydraulic oils must comply with the following requirements :

- Oil filterability must be compatible with absolute filters
- Have properties such as :
 - Antifoam and deaeration
 - Anti-wear, anti-shear and antioxydant
 - Rust and corrosion inhibitors (copper)

The recommended viscosity grades depending on the environmental conditions are as follows :

Environmental conditions	ISO Viscosity grade
Ambient temperature between - 15° C (- 9° F) and + 40° C (+ 104° F)	HV 46
Ambient temperature between - 35° C (- 31° F) and + 35° C (+ 95° F)	HV 32
Ambient temperature between 0° C (32° F) and + 45° C (+ 113° F)	HV 68

Biodegradable oils may be used if they comply with the following requirements :

- Ambient operating temperature between - 15° C (- 9° F) and + 40° C (+ 104° F)
- HEES type biodegradable oil only according to standards ISO 15380 and VDMA 24568
- Necessary characteristics :

Viscosity grade	ISO Viscosity grade
Viscosity at + 40° C (+ 104° F)	46 +/- 3 mm ² / s
Viscosity at + 100° C (+ 260° F)	> 8 mm ² / s
Viscosity index	> 160
Flashpoint	> 220° C (> 572° F)
Pour point	< - 40° C (> - 104° F)

C-Familiarization

6 - Machine specifications

6.1 - MOVEMENT SPEED

To allow checking operation, refer to the following table about originally time per movement. If the values measured by test are not equal to the following :

- Do not use the machine.
- Setting updating is needed.

Always check speed movement from the ground control box.

	HA18PX - HA51JRT
Time for arm lifting	35s ± 3s
Time for descent arm	23s ± 3s
Time for raising boom	30s ± 3s
Time for descent boom	33s ± 3s
Time for continue turntable rotation	75s ± 1.5s (per 1/2 rotation)
Time for telescopic boom extension	20s ± 3s
Time for telescopic boom retraction	16s ± 3s
Time for jib lifting	34s ± 2s
Time for jib descent	35s ± 2s
Time for raising compensation	27s ± 5s
Time for lowering compensation	35s ± 5s

D-Inspection and maintenance schedule

1 - Inspection program

The machine must be inspected at regular intervals in accordance with the requirements set out in the country of use and at least once a year. The purpose of the inspection is to detect any defect which could lead to an accident during routine use of the machine.

Inspections and maintenance must be carried out by a qualified company or person chosen by the owner of the machine.

The results of these visits must be recorded in a safety register created by the owner. This register as well as the list of competent repair persons must be made available to the work inspector, government inspector and company safety committee at any time.

Frequency	Person-in-charge	Stakeholder	Type	Documentation
Before each hire	Owner	On-site technician	Daily inspection	Operator's manual
Before each use or each change of user	Operator	Operator	Daily inspection	Operator's manual
At intervals recommended by HAULOTTE®	Owner	On-site technician, qualified HAULOTTE Services® technician	Preventive maintenance	Maintenance Book
Before sale	Owner	On-site technician, qualified HAULOTTE Services® technician	Periodic inspection	Maintenance Book
Annually (1 year) (*)	Owner	On-site technician, qualified HAULOTTE Services® technician	Periodic inspection	Maintenance Book
After 10 years then every 5 years	Owner	Qualified technician HAULOTTE Services®	Major inspection	Maintenance Book

(*) Or according to local regulations.

D-Inspection and maintenance schedule

2 - Daily inspection

The daily inspection must be performed every day, before the start of a new work shift and at every change of user.

This inspection is performed by and under the responsibility of the user and includes the visual and functional inspection of the machine as well as the testing of its safety systems.

A description of the daily inspection can be found in the machine's user manual.

We recommend these forms to be completed daily and stored to assist with your maintenance schedule.

3 - Preventive maintenance









Maintenance operations must be carried out by a qualified technician chosen by the owner and ensure that the machine operates correctly.

Severity of operating conditions may require a reduction in time between maintenance periods.



Maintenance operations performed must be recorded in a register / log book of the machine.



The information contained in our manual is to be complemented by the information found in the engine manufacturer's maintenance manual, which can be found on the link in the associated maintenance sheet MS0238.








	Oil change		Lubrication-Lubrication		Tightening
	Levelling		Systematic replacement		Functional adjustments / Checks / Cleaning
	Visual inspection		To check by test		

Preventive Maintenance Level 1 - First 50H

First 50H	Page or associated procedure	First 50H	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Tighten the wheel nuts						
Hydraulic : oils, filters and hoses						
Replace the hydraulic filter						

D-Inspection and maintenance schedule



Preventive Maintenance Level 1 - Every 200H

Every 200H	Page or associated procedure	Every 200H	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Grease the steering system						
Grease the bushings and pins						
Drain the wheel reducer**						
Slew ring						
Grease the turntable slew ring						
Drain the movement reducer**						
DEUTZ 2011 engine						
Clean the air filter						
Arm, boom						
Grease the pads						

** Only in the first 200H

D-Inspection and maintenance schedule

Preventive Maintenance Level 1 - Every 6 months or 500H

Every 6 months or 500H	Page or associated procedure	Every 6 months or 500H	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Tighten the wheel nuts						
Check the wheel reducer level						
Tighten the steering system						
Slew ring						
Tighten the slew ring						
Check the movement reducer level						
DEUTZ 2011 engine						
Drain the engine oil*						
Replace the oil filter*						
Hydraulic : oils, filters and hoses						
Check the hydraulic oil level						
Jib						
Tighten the rotary cylinder						
Tighten the load cell						
Platform						
Tighten the mounting on the platform support, the platform floor and the platform access						

* Do not take into account the deadline of 6 months, only 500H.






D-Inspection and maintenance schedule

Preventive Maintenance Level 2 - Every 1 year or 1000H


Every 1 year or 1000H	Page or associated procedure	Every 1 year or 1000H	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Drain the wheel reducer						
Slew ring						
Drain the movement reducer						
DEUTZ 2011 engine						
Replace the fuel filter						
Replace the air filter						
Check tension and status of the distribution belt						
Replace alternator belt						
Hydraulic : oils, filters and hoses						
Replace the hydraulic filter						
Arm, boom						
Check the pads-Replacement is necessary						

D-Inspection and maintenance schedule

Preventive Maintenance Level 2 - Every 2 years or 2000H

Every 2 years or 2000H	Page or associated procedure	2 year(s) or 2000H	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Check the bushings and pins-Replacement is necessary						
Slew ring						
Check the slew ring clearance						
DEUTZ 2011 engine						
Drain the oil tank						
Drain the cooling circuit						
Hydraulic : oils, filters and hoses						
Drain the hydraulic oil						

Preventive Maintenance Level 2 - Every 5 years or 5000H

Every 5 years or 5000H	Page or associated procedure	Every 5 years or 5000H	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Replace distribution belt						

D-Inspection and maintenance schedule

4 - Periodic inspection

The Periodic inspection is a thorough inspection of the operation and safety features of the machine. This must take place prior to the sale or resale of the machine and every 1 year. Local regulations may have specific requirements on frequency, and content of inspections.










This intervention must take place after :

- Extensive dismantling and reassembly
- Repairs involving the machine's essential components
- Any accident causing stress to the machine

This inspection is the responsibility of the owner, and must be conducted by a qualified technician.

Under no circumstances may this inspection replace the control required by local regulations.

Use the detailed program below.

Periodic	Page or associated procedure	Periodic	OK	NOK	Corrected	Comments
Chassis assembly : Wheel, reducer, steering, wheel pivot						
Check state of tires/tyres and inflations						
Motor						
Check that there are no leaks from the engine's components (engine, hose, radiator)						
Check the condition of the battery						
Check for visible damage and broken welds on the exhaust system						
Check the operation of the lock on the engine casing						
Turntable						
Test the operation of the turntable locking system						
Hydraulic : oils, filters and hoses						
Check the hoses, blocks and pumps, fittings, cylinders and the tank for the absence of leaks, deformations and damage						
Platform						
Test the automatic closure and locking of access basket						
Check that the harness anchor points are not cracked or damaged						

D-Inspection and maintenance schedule

Periodic	Page or associated procedure	Periodic	OK	NOK	Corrected	Comments
General						
Check for the presence, cleanliness and readability of the manufacturer's plates, security labels, user manual and maintenance manual						
Check the cleanliness and readability of the control box						
Test the opening and closure of covers (chassis, turntable, upper control box)						
Check the condition of electrical harnesses, cables and connectors						
Check for the absence of abnormal noise and jerky movements						
Check for the absence of visible deterioration and damage						
Check for the absence of cracks, broken welds and chipped paintwork on the structure						
Check for the absence of missing or loose screws and bolts						
Check for the absence of deformation, cracking and breakage of axis stops, bushing and axes						
Check for the absence of foreign bodies in joints and sliding parts						
Safety devices						
Test the operation of the upper and lower control boxes: manipulators, switches, buttons, horn, emergency stops, screens and lights						
Check for the absence of visual and audible alarms						
Test the operation of the tilt system						
Test the operation of the emergency lowering system						
Test the operation of the axle locking system						
Test the operation of the loading control system (visual alarm on the control box)						
Test the operation of the Activ Shield Bar (If equipped)						
Test the operation of the drive speed limiter systems						
Test the speed and behavior of movements						
Check the operation of the load control system- Calibrate if necessary						

D-Inspection and maintenance schedule

5 - Major inspection

The inspection is a thorough inspection of the machine to ensure that it is fully functional. It must be carried out after 10 years then every 5 years.

This inspection is the responsibility of the owner and must be carried out by a technician HAULOTTE Services® or an authorized and qualified person.

In order to carry it out, contact the subsidiary HAULOTTE® or the authorized distributor.

N.B.:--THE LIST OF MAINTENANCE SHEETS IS NOT EXHAUSTIVE. OTHER SHEETS MAY BE SENT UPON REQUEST. CONTACT HAULOTTE SERVICES®.

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

Exclusively use tools and auxiliary average adapted. Always wear necessary safety clothing.

For safety reasons, imperatively respect the following stages during the tests :

- To set up the beaoning of safety around the test area.
- To put the machine in position transport (horizontal jib accepted)
- Use safety straps.

2 - Preliminary operation

The operations of disassembling if they exist should be carried out only on the installations completely disconnected and must be entrusted only to people having the necessary technical training.

Respect, in addition to the instructions appearing in the present instructions, the legal tendencies generally applicable for safety accident prevention.

All the precautions must be done in work before intervening on and near the machine.

After completion of work, all the covers and safety devices must be positioned back completely and operational.

3 - Control and maintenance

To guarantee the integrity of the machine, it is necessary to carry out periodical controls on the mechanical structure such as defines hereafter.


3.1 - DAILY INSPECTION

All the accessible structural part without disassembling must be subjected to a fast visual inspection.


If anomalies are noted, according to the list below, a reinforced control will have to be carried out to judge conformity of the part :

- Absence of foreign body to the articulations and slides.
- Absence of deformation and visible damage.
- Absence of crack, broken welding, oxidation, glare of painting.
- Absence of excessive gap to the articulations and slides.
- Check that locking device are not damaged and are functional.
- No screws or missing part loosened or unscrew.
- Anchorage points firmly fixed and not damaged.

The list of part to check are define Section Familiarization.



3.2 - MAJOR INSPECTION


All structural part listed Section Familiarization must be disassembled and all welds must be review using non-destructive checks  Section D Inspection and maintenance schedule.

The criteria quoted above are applicable.

The main items to be inspected are :

- Boss welds on chassis, turret, arms, booms and jib.
- Booms and arms welds.

Example



In the event of suspicion of crack, a cleaning and a sweating are to be carried out to guarantee the integrity of the part before reassembly.

Check presence and torque of each bolts and screw used to assembly part listed in Section Familiarization. Refer to spare part catalog for additional information if needed.



Some screws are not reusable and must be systematically changed (ex: screws from the gear ring).

3.3 - FUNCTIONAL TESTS

The following tests must be performed periodically  Section D Inspection and maintenance schedule :

- An important technical intervention.
- An accident resulting from a failure of a major component.

The following tests must be realized by a qualified staff under secure conditions.

The results of the tests must be entirely documented.

To avoid the swing of the machine during the test, it is imperative that a device of reserve (chain, not of anchoring) is used during the test.

3.4 - DYNAMIC TESTS

The machine must be place on level and firm ground.

With 100% of the maximum allowed load, operate from ground control box (or emergency control box) all the movements ; the platform floor must reach a height of about 1 above the ground.

The functional tests must show the following facts :

- The machine carried out all the movements without jolts while supporting the load.
- All the security device function correctly.
- Authorized maximum speeds of operation are not exceeded.

Refer to the user manual for the description of the safety device and technical characteristics to be reached.

3.5 - STRUCTURAL TEST (OVERLOAD)

The following test shows that the structure of the machine is in conformity with the safety requirements.

The machine must be place on level and firm ground.

With 100% of the maximum allowed load, operate from ground control box (or emergency control box) all the movements ; the platform floor must reach a height of about 1 above the ground :

- Measure the distance between the ground and the basket (or of the platform).
- Leave the machine in static during 15 mnn.
- Measure the distance between the ground and the basket (or of the platform).

If the difference between two measurements does not exceed 4 cm (1.575 in) : the test is validated.

If the difference between two measurements exceeds 4 cm (1.575 in), to contact HAULOTTE Services® or to carry out the additional tests described below.  MS0003 - § 3.2 Cylinder inspection.

1 - You will need




- Standard tool kit
- Protective goggles
- Gloves
- Oil collection pan




- Place barriers around the perimeter of the work area

2 - Preliminary procedure

1. Place the machine in maintenance configuration.  3.3.1-Placing the machine in maintenance configuration


3 - Control

1. Turn the wheel to obtain the following configuration :
 - Plug (1) is on a horizontal line.
 - Plug (2) is on a vertical line.
2. Loosen and remove plug (1).
3. Check the oil level.
4. Top up the oil level to the hole, if necessary.
5. Refit and tighten plug (1).



4 - Oil change

1. Turn the wheel until plug (2) is directed downwards.
2. Loosen and remove plugs (1) and (2).
3. Let the oil drain out.
4. Refit and tighten plug (2).
5. Turn the wheel again to the level control position.
6. Fill the wheel reducer with oil up to hole (1)
7. Refit and tighten plug (1).



Use an oil collection pan to avoid polluting the environment.

5 - Additional operation

1. Place the machine in its operating configuration.  3.3.2-Placing in operating configuration

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

Exclusively use tools and auxiliary average adapted. Always wear necessary safety clothing.

2 - Preliminary operation


The operations of disassembling if they exist should be carried out only on the installations completely disconnected and must be entrusted only to people having the necessary technical training.




Respect, in addition to the instructions appearing in the present instructions, the legal tendencies generally applicable for safety accident prevention.

All the precautions must be done in work before intervening on and near the machine.

After completion of work, all the covers and safety devices must be positioned back completely and operational.

3 - Control and maintenance

Inspection of the pins, stop pins, bushings and bearings must be carried out according to the recommendations  Section D Inspection and maintenance schedule :

- Fast visual inspection without disassembling  Section D Inspection and maintenance schedule :
 - Check the presence of the pins and visible stops pins without disassembling.
 - Check the presence of the screws.
 - Check absence of deformations, cracks or breakage of pins and/or stops pins.
 - Check absence of heavy abrasion, wear or oxidation of the pins, stops pins.
- Reinforced visual inspection with disassembling of certain elements to reach the bushes or bearing  Section D Inspection and maintenance schedule : In addition to the above cited criteria, verify the following :
 - Check the presence and the position of the bushes and bearings.
 - Check the absence of shaving in periphery of the pins.
 - Check the absence of heavy abrasion, wear or oxidation of the bushes and bearing.
 - Check the absence of deformations, cracks or breakage of the bushes and bearing.
 - Check the absence of radial gap $> 0,5 \text{ mm}$ ($19690 \mu \text{ in}$) on the pins.
- Complete disassembling of the pins, bushes and bearing  Section D Inspection and maintenance schedule : In complement of the inspections above cited, it is necessary to check :
 - For the stages :
 - Check the presence of material of friction.
 - For the bearings :
 - After disassembling, protect the bearing from pollution and shocks.
 - Clean the bearing with a suitable solvent.
 - Check the absence of shaving in the housing of the bearing and/or the bearing.
 - Check the absence of heavy abrasion, wear, oxidation, deformations of the balls (or rollers) and the ball races.

The periodicity can evolve under the following conditions  Section D Inspection and maintenance schedule :

- Abnormal noise during movements of the structure.
- Prolonged storage of the machine (6 months).
- Specific storage and use Environment (strong moisture and salinity of the air).

4 - Criteria of replacement

The pins, stop pins, bushes and bearing must be replaced as soon as one of the anomalies quoted above is noted. Bearing and bushes must be imperatively changed at the end of 10 years of use.


5 - Procedure of reassembly

5.1 - PINS AND BUSHES

When reassembling bearings and pins ensure that :

- Lightly lubricate the housing into which the bearing is to be installed.
- Insert the bearing using a bearing drift, preferably out of mild steel.
- The bearing, the bearing drift and the bearing housing must be correctly aligned during the assembly process.
- The recommended values for the bearing drift are given on the diagram below :

Recommended Values



Marking	Description
A	At least 0,5 times the nominal diameter
B	Make a chamfer
C	Nominal diameter of the bearing - 0,2 / - 0,3 mm (-7874 μ in / -11810 μ in)
D	Bearing drift
E	Diameter of the bearing guide - 0,20 / - 0,25 mm (-7874 μ in / -9843 μ in)
F	Bearing
G	Housing

- After inserting the bearing, lubricate and fit the pin.

5.2 - BEARINGS

For the reassembly of bearings, respect the following stages :

- Clean boring and/or the pins to remove all the foreign bodies.
- Slightly lubricate boring and/or pins.
- Lubricate the ring of the bearing slightly.
- To fit bearing in a boring: take support on the external ring of the bearing.
- To fit bearing on an axis: take support on the interior ring of the bearing.

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

Exclusively use tools and auxiliary average adapted. Always wear necessary safety clothing.

For safety reasons, imperatively respect the following stages during the tests :

- To set up a beaconing of safety around the test area.
- Put the machine in stowed position.
- Use safety straps.

2 - Preliminary operation

The operations of disassembling if they exist should be carried out only on the installations completely disconnected and must be entrusted only to people having the necessary technical training.

Respect, in addition to the instructions appearing in the present instructions, the legal tendencies generally applicable for safety accident prevention.

All the precautions must be done in work before intervening on and near the machine.

After completion of work, all the covers and safety devices must be positioned back completely and operational.

3 - Control and maintenance

3.1 - VISUAL INSPECTIONS

The hydraulic actuating cylinders must be subjected to visual inspections periodic all the 250 hours or 6 months such as defined below :

- Absence of leakage.
- Absence of deformations, visible damage , cracks on the body and fixing of the cylinder.
- Absence of rust and shock on the rod.
- Absence of foreign objects on all surfaces.
- Absence of missing or loosened part (bolt, nut, connection, flexible device, etc).

3.2 - FUNCTIONAL TESTS

To guarantee an optimal level of performance and safety, functional tests must be realized all the 250 hours or 6 months.

The periodicity can evolve under the following conditions :

- Anomaly noted during visual inspection.
- Abnormal noise during movements of the structure.
- Prolonged storage of the machine (6 months).
- Specific storage and use Environment (strong moisture and salinity of the air).

Generic Control :

- Position a load equal to the rated capacity on the cage (or platform).
- Raise the cage (or the platform) using the ground control box. To activate the cylinder to be tested, proceed as follows :
 - Lift Arm hydraulic cylinder : Lift the arm to approximately half full height. The telescopic boom should be fully extended and in the horizontal position. (For machines fitted with).
 - Boom lifting cylinder or Jib cylinder : Lift the concerned equipment (boom or jib) of approximately half way. Extend the telescope to its maximum.
 - Telescoping cylinder : Lift the boom to its maximum angle and telescope approximately 50 cm (19.69 in).
- Measure the distance between the floor of the cage (or of the platform) and the ground.
- Leave the machine in this condition for 15 mn (minutes).
- Measure the distance between the floor of the cage (or of the platform) and the ground.
 - If the difference between two measurements does not exceed 4 cm (1.575 in) : the test validates correct operation.
 - If the difference between two measurements exceeds 4 cm (1.575 in), contact HAULOTTE Services® or carry out the additional tests described below.

Control cylinder by cylinder :

- Position a load equal to the rated capacity on the cage (or platform).
- Perform the movement of the concern cylinder to half of its stroke.
- Fix the cylinder with a comparator :
 - Attach the body of the comparator on the cylinder rod.
 - The needle of the comparator must be in contact with the end of the casing of the cylinder.
 - The target is to measure the creep of the cylinder rod.

- If the creep of the cylinder rod is higher than the values indicated in the table below, replace the cylinder.

Type of cylinders	Maximum drift authorised due to an internal leak of the cylinder	
Lift cylinder arm or boom (Machine with working heights > 26 m(85 ft4 in))	After 10 mn, creep < 0,2 mm (7874 µ in)	After 60 mn, creep < 1 mm (0.039 in)
Outriggers cylinder, Oscillating axle locking, Lift cylinder arm or boom (Machine with range-limiting system)	After 10 mn, creep < 0,5 mm (0.01196 in)	After 60 mn, creep < 2,5 mm (0.098 in)
Lift cylinder arm or boom, Telescoping, Compensation, ...	After 10 mn, creep < 1 mm (0.039 in)	After 60 mn, creep < 6 mm (0.236 in)
Steering cylinder	After 10 mn, creep < 1,5 mm (0.059 in)	After 60 mn, creep < 9 mm (0.354 in)




These tests must be made in conditions of equivalent temperatures.

3.3 - MAJOR INSPECTION

A thorough inspection of the structural parts must be realized all the 5000 h or 10 years with disassembling of the element to check the entirety of the welding. Each Cylinder must be disassembled and must be review using non-destructive checks.

The criteria quoted above are applicable :

- Absence of deformation and visible damage.
- Absence of crack, broken welding, oxidation, glare of painting.



Check :

1. Pipe weld connection.
2. Rod weld connection.
3. Ring.
4. Rod.
5. Piston.

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

2 - Preliminary procedure

1. Place the machine in maintenance configuration.  3.3.1-Placing the machine in maintenance configuration

3 - Filling-up



Touch the exterior of the filling hole with the pump spout before starting pouring to avoid any risk of static electricity causing sparks.

Make sure you are standing up-wind to avoid being splashed by the fuel.




Do not smoke.

- Loosen and remove the tank cap .
- Fill up the tank.
- Refit and tighten the tank cap .
- Clean up any fuel that may have escaped from the tank.



4 - Additional operation

1. Place the machine in its operating configuration.  3.3.2-Placing in operating configuration

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

Exclusively use tools and auxiliary average adapted. Always wear necessary safety clothing.

For safety reasons, imperatively respect the following stages during the tests :

- Set up a beaconing of safety around the test area.
- Put the machine in position transport (Pendular horizontal accepted).
- Use safety straps.

2 - Preliminary operation


The operations of disassembling if they exist should be carried out only on the installations completely disconnected and must be entrusted only to people having the necessary technical training.

Respect, in addition to the instructions appearing in the present instructions, the legal tendencies generally applicable for safety accident prevention.

All the precautions must be done in work before intervening on and near the machine.

After completion of work, all the covers and safety devices must be positioned back completely and operational.

3 - Test procedure

The brake system is a significant component of the safety of the machine. The following tests must be performed periodically  Section D Inspection and maintenance schedule.

High speed :

- On a flat ground or slightly inclined (always lower than the authorized slope: see plate manufacturer).
- Trace on the ground, a line being used as reference mark of stop.
- Roll moving front until reaching maximum speed :
- Between 3 km/h (1.9 mph) and 6,5 km/h (4,039 mph) according to the machines.
- Release the manipulator as soon as the wheels axles are on the level of the traced reference mark.
- Stopped machine, measure the distance between the wheel axles and traced reference mark on the ground :
- If the distance lies between 0.2 m (0ft 8in) and 2,7 m (8 ft 11 in), the test is validated.
- If not, Contact HAULOTTE Services® to repair the system.

1 - You will need




- Standard tool kit
- Steel shims
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

2 - Preliminary procedure

1. Place the machine in maintenance configuration.  3.3.1-Placing the machine in maintenance configuration


3 - Lubrication



The illustrations in this paragraph do not necessarily correspond to the range of products designated in the manual.

The maintenance of the slew ring is essential for the safety of the machine and to guarantee its service life. Whatever the type of system installed on the machine, interior or external teeth, follow the recommendations of greasing as indicated in the program.

1. Check for the presence of all the locating bolts.
2. Check that the accessible screws are not loosened. If necessary, tighten the screws (Refer to the "tightening torque" table).
3. Visually check the presence of the teeth and gear (if possible).
4. Check the appearance of the teeth.
5. Grease the (internal and external) crown gear teeth.
6. Grease the raceways (access to greasers via the holes situated on the turntable, until the oil escapes from the crown lip seal).



4 - Tightening

Machine type	Metric	Imperial
HA16PE	21,5 daN.m	(158 lbf.ft)
HA12IP - HA33JE	9 daN.m	(66 lbf.ft)
HA15IP - HA43JE	9 daN.m	(66 lbf.ft)
HA12CJ - HA32CJ	9 daN.m	(66 lbf.ft)
HA12CJ+ - HA32CJ+	9 daN.m	(66 lbf.ft)
HA120PX (N/A)	9 daN.m	(66 lbf.ft)
HA16X (N/A)	21,5 daN.m	(158 lbf.ft)
HA16SPX - HA46SJRT	21,5 daN.m	(158 lbf.ft)
HA16PX - HA46JRT	21,5 daN.m	(158 lbf.ft)
HA18SPX - HA51SJRT	21,5 daN.m	(158 lbf.ft)
HA18PX - HA51JRT	21,5 daN.m	(158 lbf.ft)
HA20PX - HA61JRT	21,5 daN.m	(158 lbf.ft)
HA260PX - HA80JRT	21,5 daN.m	(158 lbf.ft)
HA32RTJ PRO - HA100RTJ PRO	21,5 daN.m	(158 lbf.ft)
HA41RTJ PRO - HA130RTJ PRO	21,5 daN.m	(158 lbf.ft)
H14TX - HB40	8,7 daN.m	(64 lbf.ft)
H16TPX - HB44J	8,7 daN.m	(64 lbf.ft)
H21TX - HB62	21,5 daN.m	(158 lbf.ft)
H23TPX - HB68J	32 daN.m	(236 lbf.ft)
H25TPX - HB76J	21,5 daN.m	(158 lbf.ft)
H28TJ+ - HB86TJ+	21,5 daN.m	(158 lbf.ft)
HT43RTJ PRO - HT132RTJ PRO	21,5 daN.m	(158 lbf.ft)
STAR 8 - STAR 22J - Ring on plate	13.5 daN.m	(100 lbf.ft)
STAR 8 - STAR 22J - Plate on mast foot	19.5 daN.m	(144 lbf.ft)
STAR 8 - STAR 22J - Ring on chassis	13.5 daN.m	(100 lbf.ft)
STAR 10 - STAR 26J - Ring on plate	13.5 daN.m	(100 lbf.ft)
STAR 10 - STAR 26J - Plate on mast foot	19.5 daN.m	(144 lbf.ft)
STAR 10 - STAR 26J - Ring on chassis	13.5 daN.m	(100 lbf.ft)

5 - Criteria of replacement

Check the slewing system every 500 h or each major intervention done on the machine.

Step 1 : Visual and sound check :

Replace slew ring in the following cases :

- Abnormal noise during the turret rotation.
- Movement jolts during the rotation of the turret.
- Gear teeth missing or damaged.
- Presence of metal particles in the grease.
- Wear on gear teeth.


Step 2 : Measurement of the clearance :

Place the machine in the following conditions :

- On flat ground, Set up barriers to define the test area.
- No load in the platform.
- From the ground control box, align the turret at 90 ° to the chassis.
- Lift the boom approximatively 30 ° from the ground.
- Completely retract the boom.
- Jib in horizontal position(if fitted).

From the magnetic comparator, note the clearance (J1) between chassis (or turret) and the slew ring.

Clearance between chassis (or turret) and slew ring



After having carried out the measurement :

- Lower the boom at horizontal position.
- Lift the arm (if exists) as its maximum position. Don't extend the telescopic boom.
- The telescopic boom should be fully extended and in the horizontal position..
- Jib in horizontal position(if fitted).

In its new configuration, note the clearance (J1) between chassis (or turret) and the slew ring as previously.


- If the difference between two measurements does not exceed 2 mm : the test validates correct operation.
- Otherwise, contact HAULOTTE Services® to repair the system.

6 - Clearance check



Consult the After-Sales Service HAULOTTE Services®.

7 - Additional operation

1. Place the machine in its operating configuration.  3.3.2-Placing in operating configuration
2. Rotate the slew ring by one complete turn.




A tight spot or grinding sound during rotation or the presence of metal particles escaping from the lip seal are signs of abnormal wear in the raceway (Contact HAULOTTE Services®).

1 - Metric torque chart

For screws HAULOTTE®, use columns (A), (B) and (C) :

- Screw (1) grey dull dry, use colums (A)
- Screw (1) grey dull greasy, use column (B)
- Screw (2) yellow dry, use column (C)
- Screw (2) yellow greasy, use column (B)
- Screw (3) grey bright dry, use column C
- Screw (3) grey bright greasy, use column (B)



Metric fastener torque chart
This charts is to be used as a guide only unless noted elsewhere in this manual

Size (mm)	Class 4.6						Class 8.8						Class 12.9											
	Dull dry (A)		Lubed (B)		Yellow dry (C)		Dull dry (A)		Lubed (B)		Yellow dry (C)		Dull dry (A)		Lubed (B)		Yellow dry (C)		Dull dry		Lubed		Yellow dry	
	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
5	17.7	2	16	1.8	21	2.4	44	5	41	4.63	54	6.18	68	7.7	58	6.63	78	8.84	79	9	68	7.75	91	10.3
6	30	3.4	19	3.05	36	4.07	80	9.1	69	7.87	93	10.5	118	13.4	100	11.3	132	15	139	15.7	116	13.2	155	17.6
Size (mm)	Dull dry		Lubed		Yellow dry		Dull dry		Lubed		Dry		Dull dry		Lubed		Dry		Dull dry		Lubed		Dry	
	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
	8	5.9	8	5.4	7.41	7.2	9.88	16.2	22	14	19.1	18.8	25.5	23.6	32	20.1	27.3	26.9	36.5	28	38	23.6	32	31.4
10	12.17	16.5	10.8	14.7	14.4	19.6	32.45	44	27.9	37.8	37.2	50.5	47.2	64	39.9	54.1	53.2	72.2	55	75	46.7	63.3	62.3	84.4
12	20.65	28	19.8	25.6	25.1	34.1	56	76	48.6	66	64.9	88	81.8	111	69.7	94.5	92.2	125	95.9	130	81	110	108	147
14	33.19	45	30.1	40.8	40	54.3	89.24	121	77.4	105	103	140	131.28	178	110	150	147	200	154.15	209	129	175	172	234
16	52.37	71	46.9	63.6	62.5	84.8	139.4	189	125	170	166	226	205.04	278	173	235	230	313	239.7	325	202	274	269	365
18	72.28	98	64.5	87.5	86.2	117	192.5	261	171	233	229	311	283.2	384	238	323	317	430	331	449	278	377	371	503
20	102.5	139	91	124	121	165	272.9	370	243	330	325	441	401.2	544	337	458	450	610	469.8	637	394	535	525	713
22	140.87	191	124	169	166	225	345.4	509	331	450	442	600	551.7	748	458	622	612	830	645.3	875	536	727	715	970
24	176.27	239	157	214	210	285	469.8	637	420	570	562	762	690.3	936	583	791	778	1055	807.6	1095	682	925	909	1233

2 - SAE fastener torque chart

SAE fastener torque chart											
This chart is to be used as a guide only unless noted elsewhere in this manual											
Size	Thread	Grade 5				Grade 8				A574 High strength black oxide bolts	
		Lubed		Dry		Lubed		Dry		Lubed	
		in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
1/4	20	80	9	100	11.3	110	12.4	140	15.8	130	14.7
	28	90	10.1	120	13.5	120	13.5	160	18	140	15.8
		Lubed		Dry		Lubed		Dry		Lubed	
		ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
5/16	18	13	17.6	17	23	18	24	25	33.9	21	28.4
	24	14	19	19	25.7	20	27.1	27	36.6	24	32.5
3/8	16	23	31.2	31	42	33	44.7	44	59.6	38	51.5
	24	26	35.2	35	47.4	37	50.1	49	66.4	43	58.3
7/16	14	37	50.1	49	66.4	50	67.8	70	94.7	61	62.7
	20	41	55.5	55	74.5	60	81.3	80	108.4	68	92.1
1/2	13	57	77.3	75	101.6	80	108.4	110	149	93	126
	20	64	86.7	85	115	90	122	120	162	105	142
9/16	12	80	108.4	110	149	120	162	150	203	130	176
	18	90	122	120	162	130	176	170	230	140	189
5/8	11	110	149	150	203	160	217	210	284	180	244
	18	130	176	170	230	180	244	240	325	200	271
3/4	10	200	271	270	366	280	379	380	515	320	433
	16	220	298	300	406	310	420	420	569	350	474
7/8	9	320	433	490	583	450	610	610	827	510	691
	14	350	474	470	637	500	678	670	908	560	759
1	8	480	650	640	867	680	922	910	1233	770	1044
	12	530	718	710	962	750	1016	990	1342	840	1139
1 1/8	7	590	800	790	1071	970	1315	1290	1749	1090	1477
	12	670	908	890	1206	1080	1464	1440	1952	1220	1654
1 1/4	7	840	1138	1120	1518	1360	1844	1820	2467	1530	2074
	12	930	1260	1240	1681	1510	2047	2010	2725	1700	2304
1 1/2	6	1460	1979	1950	2643	2370	3213	3160	4284	2670	3620
	12	1640	2223	2190	2969	2670	3620	3560	4826	3000	4067


1 - You will need

- Standard tool kit
- Protective goggles
- Gloves
- Jack
- Hoist
- Torque spanner



- Place barriers around the perimeter of the work area


2 - Preliminary procedure

1. Place the machine in maintenance configuration.  3.3.1 -Placing the machine in maintenance configuration


3 - Criteria of replacement

Replace the wheels and the tires if any of the following conditions exist :

- Presence of cracks, damage, deformation or other faults on the hub
- Damage to the tire :
 - Cut or hole > 3 cm (2 in) in the rubber side wall.
 - Blister or pronounced lump on the external and lateral wall.
 - Damaged wheel stud.
 - Damage or wear on the side wall to the extent that the reinforcing wire is visible.
- Nonlinear wear of the ground contact surface greater than 10 %.



- Consistent wear of the ground contact surface greater than 25 %.



For safety reasons, always use original HAULOTTE® spare parts that are specific to this machine. Refer to the spare parts catalog.

4 - Replacement

1. Loosen the wheel nuts on the wheel to be removed.
2. Raise the machine using a jack or a hoist.
3. Remove the wheel nuts.
4. Remove the wheel.
5. Install the new wheel.
6. Lower the machine to the ground.
7. Tighten the wheel nuts to the recommended torque




5 - Torque

Machine type	Wheel type	Torque in N.m - lbf.ft
HA12CJ - HA32CJ	Drive wheel	210-155
	Steer wheel	210-155
HA12CJ+ - HA32CJ+	Drive wheel	210-155
	Steer wheel	210-155
HA120PX (N/A)	Drive wheel	320-236
	Steer wheel	320-236
HA16X	Drive wheel	320-236
	Steer wheel	320-236
HA16SPX - HA46SJRT	Drive wheel	320-236
	Steer wheel	320-236
HA16PX - HA46JRT	Drive wheel	320-236
	Steer wheel	320-236
HA18SPX - HA51SJRT	Drive wheel	320-236
	Steer wheel	320-236
HA18PX - HA51JRT	Drive wheel	320-236
	Steer wheel	320-236
HA20PX - HA61JRT	Drive wheel	320-236
	Steer wheel	320-236
HA260PX - HA80JRT	Drive wheel	320-236
	Steer wheel	320-236
HA32RTJ PRO - HA100RTJ PRO	Drive wheel	650-479
	Steer wheel	650-479
HA41RTJ PRO - HA130RTJ PRO	Drive wheel	570-420
	Steer wheel	570-420
H12 SX - HS3388 RT H12 SXL - HS3388 RT XL - H15 SX - HS4388 RT - H15 SXL - H18 SX - HS5388 RT - H18 SXL	Drive wheel	320-236
	Steer wheel	320-236
H14TX - HB40	Drive wheel	320-236
	Steer wheel	320-236
H16TPX - HB44J	Drive wheel	320-236
	Steer wheel	320-236
H21TX - HB62	Drive wheel	320-236
	Steer wheel	320-236
H23TPX - HB68J	Drive wheel	320-236
	Steer wheel	320-236
H25TPX - HB76J	Drive wheel	320-236
	Steer wheel	320-236
H28TJ+ - HB86TJ+	Drive wheel	650-479
	Steer wheel	650-479
HT43RTJ PRO - HT132RTJ PRO	Drive wheel	570-420
	Steer wheel	570-420
STAR 6 - STAR 13 - STAR 6 P	Drive wheel	127-94
	Steer wheel	127-94

Machine type	Wheel type	Torque in N.m - lbf.ft
STAR 8 - STAR 22J	Drive wheel	80-59
	Steer wheel	115-85
STAR 10 - STAR 26J	Drive wheel	80-59
	Steer wheel	115-85
COMPACT 10DX - COMPACT 12DX - COMPACT 2668RT - COMPACT 3368RT	Drive wheel	190-140
	Steer wheel	190-140

6 - Additional operation

1. Place the machine in its operating configuration.  3.3.2 -Placing in operating configuration

1 - Torque (coarse thread)

Nominal diameter	Torque in N.m - lbf.ft		
	Class 8.8	Class 10.9	Class 12.9
M6x1	9 - 11-6,64 - 8,11	13 - 14-9,59 - 10,33	15 - 17-11,06 - 12,54
M7x1	15 - 19-11,06 - 14,01	21 - 24-15,49 - 17,7	26 - 28-19,18 - 20,65
M8x1.25	22 - 27-16,23 - 19,91	31 - 34-22,86 - 25,08	37 - 41-27,29 - 30,24
M10x1.5	43 - 45-31,72 - 33,19	61 - 67-44,99 - 49,42	73 - 81-53,84 - 59,74
M12x1.75	75 - 94-55,32 - 69,33	110 - 120-81,13 - 88,51	130 - 140-95,88 - 103,26
M14x2	120 - 150-88,51 - 110,63	170 - 190-125,39 - 140,14	200 - 220-147,51 - 162,26
M16x2	190 - 230-140,14 - 169,64	260 - 290-191,77 - 213,89	320 - 350-236,02 - 258,15
M18x2.5	260 - 320-191,77 - 236,02	360 - 400-265,52 - 295,02	440 - 480-324,53 - 354,03
M20x2.5	370 - 450-272,9 - 331,9	520 - 570-383,53 - 420,41	620 - 680-457,29 - 501,54
M22x2.5	500 - 620-368,78 - 457,29	700 - 770-516,29 - 567,92	840 - 930-619,55 - 685,93
M24.3x3	630 - 790-464,66 - 582,67	890 - 990-656,43 - 730,19	1070 - 1180-789,19 - 870,32
M27x3	930 - 1150-685,93 - 848,2	1300 - 1400-958,83 - 1032,59	1560 - 1730-1150,6 - 1275,98
M30x3.5	1260 - 1570-929,33 - 1157,97	1770 - 1960-1305,49 - 1445,62	2200 - 2350-1622,64 - 1733,27

2 - Torque (fine thread)

Nominal diameter	Torque in N.m - lbf.ft		
	Class 8.8	Class 10.9	Class 12.9
M8x1	24 - 29-17,7 - 21,39	33 - 37-24,34 - 27,29	40 - 44-29,5 - 32,45
M10x1.25	46 - 57-33,93 - 42,04	64 - 71-47,2 - 52,37	77 - 85-56,79 - 62,69
M12x1.25	83 - 100-61,22 - 73,76	120 - 130-88,51 - 95,88	140 - 150-103,26 - 110,63
M14x1.5	130 - 160-95,88 - 118,01	180 - 200-132,76 - 147,51	220 - 240-162,26 - 177,01
M16x1.5	200 - 250-147,51 - 184,39	280 - 310-206,52 - 228,64	340 - 370-250,77 - 272,9
M18x1.5	290 - 360-213,89 - 265,52	410 - 450-302,4 - 331,9	490 - 540-361,41 - 398,28
M20x1.5	410 - 510-302,4 - 376,16	570 - 630-420,41 - 464,66	690 - 760-508,92 - 560,55
M22x1.5	550 - 680-405,66 - 501,54	780 - 870-575,3 - 641,68	920 - 1000-678,56 - 737,56
M24x1.5	690 - 860-508,92 - 634,3	970 - 1070-715,44 - 789,19	1160 - 1290-855,57 - 951,46
M27x2	1000 - 1300-737,56 - 958,83	1400 - 1560-1032,59 - 1150,6	1690 - 1880-1246,48 - 1386,62
M30x2	1400 - 1700-737,56 - 958,83	1960 - 2180-1032,59 - 1150,6	2350 - 2610-1246,48 - 1386,62

1 - You will need




- Standard tool kit
- Protective goggles
- Gloves





- Place barriers around the perimeter of the work area

2 - Preliminary procedure

1. Place the machine in maintenance configuration.  3.3.1-Placing the machine in maintenance configuration

3 - Control

Check the telescoping friction pad wear indicators. Change the pad if the indicator is not visible.




N.B.:-PACKERS OF DIFFERENT THICKNESSES CAN BE USED FOR ADJUSTMENT

4 - Replacement

Replace the friction pads.

5 - Additional operation

1. Place the machine in its operating configuration.  3.3.2-Placing in operating configuration



Notes

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

2 - Preliminary procedure



The battery manufacturer's safety instructions must be followed.

1. Place the machine in maintenance configuration.  3.3.1-Placing the machine in maintenance configuration

3 - Control

Loosen the caps located on the top of the battery.

The level of electrolyte in the battery must be approx. 0,01 m(0 ft39 in) above the plates.

4 - Filling-up

Loosen the caps located on the top of the battery.

If the level of electrolyte is below the level of the plates :

1. Top up with distilled water.
2. Refit and tighten the battery caps.



5 - Battery charge


Battery discharged :

- Never discharge the batteries to more than 80 % of their capacity in 5 h (hours).
- Never leave the batteries discharged.
- Do not put off recharging the batteries in cold weather as the electrolyte may freeze.

Battery to be charged :


- When should the batteries be charged ?
- When the batteries are discharged to between 35 % and 80 % of their nominal capacity.
- After a long period of non-use.
- How to charge the batteries ?
- Ensure that the mains supply is compatible to the charger's consumption.
- Top up the batteries with distilled water to the minimum electrolyte level if any of the elements are below this minimum level.
- Work in a clean and well-ventilated area away from naked flames.
- Open the bay.
- Use the machine's on-board charger. The charger has a charge rate compatible to the battery capacity.
- During charging :
 - The machine's electric system is automatically deactivated while the external power supply is connected to the machine.
 - Ensure that the battery are at a temperature not exceeding 45 °C(113 °F) (be careful in summer or in places with a high ambient temperature).
 - Do not remove or open the caps on the elements.
- After charging :
 - Top up the electrolyte level, if necessary.
 - Avoid overflowing.
 - Wash the top of the batteries without removing the caps.
 - Dry with compressed air or clean cloths.
 - Oil the terminals.

6 - Additional operation

Place the machine in its operating configuration.  3.3.2-Placing in operating configuration

To keep your batteries in good condition, test the density of each element once a month using a battery hydrometer, according to the temperature indicated in the curves below :

Battery charge status according to density and temperature





Notes

1 - You will need



- Standard tool kit
- Protective goggles
- Gloves



- Place barriers around the perimeter of the work area

Exclusively use tools and auxiliary average adapted. Always wear necessary safety clothing.

All hydraulic components (pump, tanks....) except cylinders must be subjected to periodic visual inspections such as defined below.

For all the visible components without disassembling a fast visual inspection must be realized every day before use :

- Absence of leakage (pump, tanks, hydraulic block, connections...).
- Absence of rust on the hydraulic blocks.
- Absence of deformations, damage, crack on tanks, pump and block hydraulics.
- Absence of foreign objects on all surfaces.
- Absence of missing or loosened part (bolt, nut, connection, flexible device, etc).
- Hydraulic oil level (to supplement if necessary, machine in folded up position).
- Presence and good state of the hydraulic oil filter (absence of filling).

For all the non visible components without disassembling a reinforced visual inspection must be realized all the 250 hours or 1 year with the same criteria as quoted above.





2 - Hydraulic filter cartridge Replacement



Clogging must be checked when hot. When cold, oil viscosity may simulate filter clogging.



Do not touch the hot parts of the hydraulic power source (engine, filters, etc.).





1. When the clogging indicator (2) comes on, replace the cartridge (1) (Cold oil).
2. Loosen and remove the base nut (3).
3. Loosen and remove the cartridge (1).
4. Screw in a new cartridge.
5. Refit and tighten the base nut (3).
6. Reset the clogging indicator (2) by pressing it until it becomes green again.



Notes

1 - You will need




- Standard tool kit
- Gloves
- Spanner 1"




- Place barriers around the perimeter of the work area

2 - Preliminary procedure

1. Place the machine in maintenance configuration.  3.3.1-Placing the machine in maintenance configuration

3 - Replacement


1. Remove the power supply lugs from the plugs (1).
2. Unscrew the plugs (2) using a spanner 1".
3. Change the plugs.



4 - Torque

- Plug torque : 55 Nm.
- Power supply lug torque : 5 Nm.

5 - Additional operation

1. Place the machine in its operating configuration.  3.3.2-Placing in operating configuration

1 - You will need



- The tracker with its cable.
- A clamp to strip the wires.
- A clamp to crimp the wires.



1



- Place barriers around the perimeter of the work area

2 - Procedure

Step 1 :



- Disconnect the plug 2.
- Remove the caps on the plug.

Step 2 :

- Pick up the pins in the plastic bag.
- Strip the wires of the tracker.
- Crimp the wires with the pins with a crimping clamp.

Step 3 :

- Take the wedgelock off the plug.
- Thread the wires in the positions regarding the information.



C1	Universal connector
Pin 1	+ permanent battery
Pin 2	GND (0 V)
Pin 3	+ battery voltage
Pin 4	<ul style="list-style-type: none"> • Machine with engine : Engine ON information. • Electrical machine : Movement and driving information.
Pin 5	Power ON information
Pin 6	
Pin 7	Movement information (Flashing light option activation)
Pin 8	Driving information
Pin 9	CAN 1 H
Pin 10	CAN 1 L
Pin 11	CAN 2 H
Pin 12	CAN 2 L

N.B.-:-REFER TO THE INSTRUCTIONS PROVIDED WITH THE TRACKER FOR THE WIRES CORRESPONDENCE. DEPENDING OF THE TYPE OF UNIT, A RESISTANCE (200 OHMS, 1 W) MUST BE INTEGRATED BETWEEN SIGNAL AND GROUND.

Step 4 :

- Put the wedgelock back on the plug to fix the pins.

Step 5 :

- Reconnect the plugs.
- Mount the tracker.
- The tracking device is operational.

E-Trouble shooting and diagram

1 - Trouble shooting

1.1 - RECOMMENDATIONS

If a malfunction occurs, check the following points :

- There is sufficient fuel.
- Sufficient engine oil.
- Sufficient hydraulic oil in the tank.
- Batteries are charging.
- Control box E-stop push-buttons are pulled out.
- The control box selector key is set to platform or ground control box.
- Control box relays are engaged.
- Fuse status.
- Ground control box solenoid valve status.

If the malfunction persists, consult the troubleshooting table to identify the problem.

IF you cannot identify the problem, contact HAULOTTE Services®.




1.2 - DESCRIPTION

The FAILURES function describes the requirements relative to failures : monitoring, information recording, information reading.



E-Trouble shooting and diagram

2 - Troubleshooting

Diagnosis

Problem	Probable cause	Solution
Engine cannot be started or stopped	Empty fuel tank	Fill the tank
	Batteries discharged	Recharge the battery or batteries
	Faulty printed circuit fuses (ground control box)	Replace the fuse(s)
	E-stop push-buttons are pushed in	Pull the E-stop buttons
	Engine in restricted mode (oil pressure indicators, overheating indicator, alternator charging indicator and clogged air filter indicator on)	See engine manufacturer's manual or contact HAULOTTE Services®
	Charge indicator bulb burnt out	Replace the bulb
	Clogged air filter indicator on	Replace the air filter cartridge
	Faulty engine safety relay	Replace the relay(s)
	Poor cable/battery terminal contact	Loosen and clean the terminals
	Faulty fuel preheating system (winter weather option)	Check and replace the plugs Check and replace the preheating relays
Low hydraulic pump pressure or power	Clogged air filter	Replace the filter
	Engine speed too low	Contact HAULOTTE Services®
	Oil leak on couplings, hoses or components	
	Clogged oil filter	Replace the oil filter cartridge See maintenance sheet E003
Platform controls do not respond	Ground control box selector key is set to ground control box position	Turn the ground control box selector key to platform control box position
	Platform overload indicator	Remove some weight Do not exceed the authorised limit  Section G 1-Main characteristics
	Enable Switch is not enabled	Enable the device and keep pressed down during movement
	Faulty joystick	Replace the joystick Contact HAULOTTE Services®
	Faulty solenoid valve for the selected movement	Replace the solenoid valve or the solenoid valve coil Contact HAULOTTE Services®
	Not enough hydraulic oil	Top up the oil level
	Tilt or slope exceeding the authorised limit	Lower the arm and boom Do not exceed the authorised limit  Section G 1-Main characteristics
No high speed	Platform extended	Fold the arm and boom
No steering	Not enough hydraulic oil	Top up the oil level
	Enable Switch is not enabled	Enable the device and keep pressed down during movement
No driving, telescope extension, boom lifting or arm lift/lower and the buzzer is on	Tilt or slope exceeding the authorised limit	Lower the arm and boom Do not exceed the authorised limit  Section G 1-Main characteristics
No turntable rotation	Turntable rotation locking pin is inserted in the chassis	Remove the pin
Hydraulic pump is making an abnormal noise	Not enough hydraulic oil	Top up the oil level
A drive wheel does not hold the road	Insufficient load on one wheel	Press the differential locking selector

E-Trouble shooting and diagram

Problem	Probable cause	Solution
Buzzer in operation	Tilt or slope exceeding the authorised limit	Lower the arm and boom Do not exceed the authorised limit  Section G 1-Main characteristics
	Platform overload indicator	Remove some weight Do not exceed the authorised limit  Section G 1-Main characteristics
	Hydraulic oil temperature too high	Allow to cool down
Pump not working	E-stop buttons are pulled out	Push in the buttons
	Faulty fuse(s)	Replace the fuse(s)
	Batteries discharged or faulty	Recharge or replace the batteries
	Poor contact on the battery cables	Clean and tighten the terminals

E-Trouble shooting and diagram

3 - Legend

3.1 - ELECTRIC CIRCUIT

Refer to  Section E 3 - Wiring diagram

3.1.1 - Main components

Nomenclature

Marking	Description
B1	Engine air filter clogging pressure switch
B2	Engine oil temperature
B3	Engine oil pressure switch
B4	Hydraulic oil overheating pressure switch
B15	Hydraulic oil overheating temperature switch for cooler option
D+	Alternator
FU1	10 A Engine power supply circuit fuse
FU2	40 A Timing box power supply circuit fuse
FU4	30 A Turntable / platform box power supply circuit fuse
FU5	3 A Turntable movement control circuit fuse
FU6	3 A Platform movement control circuit fuse
FU7	20 A Solenoid valve power supply circuit fuse
FU8	5 A Permanent power supply circuit fuse
FU9	20 A Accessory power supply circuit fuse
FU10	3 A LS valve circuit fuse
FU11	250 A Emergency pump circuit fuse
FU12	10 A 12 V Plug power supply circuit fuse
FU13	Cooler option circuit fuse
FU30	50 A Preheating fuse (Winter option)
FU31	50 A Preheating fuse (Winter option)
FU32	15 A Encoded boot power supply circuit fuse
G2	Alternator
GB1	Operating batteries
HA1	Buzzer
HA2	Buzzer — Platform control box : • Overload

E-Trouble shooting and diagram

Marking	Description
HA4	Buzzer — Ground control box : <ul style="list-style-type: none"> • Tilt sensor • Overload • Temperature • Driving buzzer option • Movement buzzer option
HL1	Battery charging indicator
HL2	Air filter clogging indicator
HL3	Engine overheating indicator
HL4	Engine oil pressure light
HL5	Beacon light option
HL6	Spotlight option
HL7	Power ON indicator
HL8	On movement flashing light LED
HL9	Fault indicator
HL13	Overload indicator
HL30	Preheating indicator (Winter option)
HM1	Enable Switch
K1	Preheating module (Winter option)
KA2	Engine start-up relay
KA43	Alternator output relay
KM2	Spark plug pre-heating relay
KM3	Spark plug pre-heating relay
KM4	Emergency pump relay
KM30	Preheating relay (Winter option)
KMG	General power supply relay
KP1	Engine power supply relay
KT2	Accelerator relay
M3	Starter
M4	Emergency pump
P1	Hour meter
SA1	Control box selection key selector
SA2	Engine speed
SA3	Differential lock
SA4	Platform rotation : <ul style="list-style-type: none"> • SA4a : Left • SA4b : Right
SA5	Platform leveling(Platform control box) : <ul style="list-style-type: none"> • SA5a : Lifting • SA5b : Lowering
SA6	Turntable jib (Ground control box) : <ul style="list-style-type: none"> • SA6a : Lowering • SA6b : Lifting
SA7	Platform jib : <ul style="list-style-type: none"> • SA7a : Lifting • SA7b : Lowering
SA8	Turntable telescope (Ground control box) : <ul style="list-style-type: none"> • SA8a : Retraction • SA8b : Extension
SA9	Platform box (or platform) telescope(Platform control box) : <ul style="list-style-type: none"> • SA9a : Retraction • SA9b : Extension
SA11	Speed selection

E-Trouble shooting and diagram

Marking	Description
SA12	Rear-axle steering : • SA12a : Right • SA12b : Left
SA13	Boom raising (Ground control box) : • SA13a : Lifting • SA13b : Lowering
SA14	Arm raises (Ground control box) : • SA14a : Lifting • SA14b : Lowering
SA15	Turntable rotation (Ground control box) : • SA15a : Right • SA15b : Left
SA16	Beacon light
SA17	Platform leveling (Ground control box) : • SA17a : Lifting • SA17b : Lowering
SA19	Emergency pump (Platform control box)
SA20	Emergency pump (Ground control box)
SB1	E-stop button (turntable)
SB2	E-stop button (cage)
SB3	Start-up switch (ground control box)
SB4	Platform start-up switch
SB5	Horn switch
SB6	Foot Switch
SB7	Horn switch (Ground control box)
SB8	Manual pre-heating
SM2	Arm raising/lowering joystick
SM4	Drive joystick : • SM4d : Right • SM4g : Left • SM4ab : Drive setpoint
SM31	Boom lifting and turntable rotation joystick
SQ1	Tilt sensor
SQ2	Jib movements cut-off
SQ3	Boom movements cut-off
SQ4	Arm movements cut-off
SQ5 - SQ6	Overloaded platform position sensor
SQ20	Right-hand rotation cut-off
SQ21	Left-hand rotation cut-off
U	HEAD electronic module
W	Frequency
YA1	Engine power supply on
YA2	Engine speed
YA3	Damper valve
YV1	LS control solenoid valve
YV2	Boom telescoping PVG : • YV2a : Extension • YV2b : Retraction
YV3	Boom lifting PVG
YV4	Arm lifting PVG
YV5	Proportional solenoid valve for turntable rotation
YV6	Driving PVG
YV8	High-speed drive control solenoid valve


E-Trouble shooting and diagram

Marking	Description
YV9	Differential locking control solenoid valve (Front axle)
YV10 - YV12 - YV17 YV23	Medium and high-speed drive control solenoid valve
YV11	Brake release control solenoid valve
YV13	High-speed drive control solenoid valve
YV14A	Turntable rotation right solenoid valve
YV14B	Turntable rotation left solenoid valve
YV15A	Compensation elevation control solenoid valve - Platform
YV15B	Compensation lowering control solenoid valve - Platform
YV18A	Jib lowering control solenoid valve
YV18B	Jib elevation control solenoid valve
YV19A	Platform rotation control solenoid valve (Left)
YV19B	Platform rotation control solenoid valve (Right)
YV21A	Reverse left-hand steering control solenoid valve
YV21B	Reverse right-hand steering control solenoid valve
YV22A	Front left-hand steering control solenoid valve
YV22B	Front right-hand steering control solenoid valve


E-Trouble shooting and diagram

3.1.2 - Fuses

Locations



Locations



E-Trouble shooting and diagram


Description of the components

Marking	Description
FU1	10 A Engine power supply circuit fuse
FU2	40 A Timing box power supply circuit fuse
FU3	80 A Accelerator circuit fuse
FU4	30 A Turntable / platform box power supply circuit fuse
FU5	30 A Turntable movement control circuit fuse
FU6	3 A Platform movement control circuit fuse
FU7	20 A Solenoid valve power supply circuit fuse
FU8	5 A Permanent power supply circuit fuse
FU9	20 A Accessory power supply circuit fuse
FU10	3 A LS valve circuit fuse
FU11	250 A Emergency pump circuit fuse
FU12	10 A 12 V Plug power supply circuit fuse
FU13	Cooler option circuit fuse
FU14	Thermostat power supply circuit fuse
FU30	50 A Preheating fuse (Winter option)
FU31	50 A Preheating fuse (Winter option)
FU32	15 A Encoded boot power supply circuit fuse


E-Trouble shooting and diagram

3.1.3 - Relays and terminals

Locations



Locations




E-Trouble shooting and diagram

Description of the components

Marking	Description
K1	Preheating module (Winter option)
KA2	Engine start-up relay
KA43	Back-up unit cut-off relay
KM4	Electric pump relay
KM30	Preheating relay (Winter option)
KMG	General power supply relay
KP1	Engine power supply relay
KT2	Accelerator relay
0	-Battery
101	+Battery
102	Emergency stop circuit
103	Starter
118	Engine speed
119	+Engine pre-heating
120	+General
240	General power supply after contactor

E-Trouble shooting and diagram

3.1.4 - Connectors



Description of the components

Marking	Description
3	<ul style="list-style-type: none"> • High jib sensor SQ2 • Start-up switch SB4
4	<ul style="list-style-type: none"> • Turret jib switch SA6 • Turntable telescoping switch SA8 • Start-up switch (ground control box) SB3 • Air filter clogging indicator HL2 • Engine overheating indicator HL3 • Engine oil pressure light HL4
8	<ul style="list-style-type: none"> • Medium and high-speed drive control solenoid valve YV12 / YV17 ; YV10 / YV23 • Brake release control solenoid valve YV11 • High-speed drive control solenoid valve YV8
10	Jib raising / lowering control solenoid valve YV18B
12	<ul style="list-style-type: none"> • Telescoping indicator HL10 • Lifting indicator HL11
14	Turntable buzzer HA4
15	Chassis solenoid valves : <ul style="list-style-type: none"> • YV22A, YV22B (Forwards drive solenoid valve) • YV21A, YV21B (Reverse drive solenoid valve) • YV13 (High-speed drive control solenoid valve) • YV9 (Differential locking control solenoid valve)
17	Jib raising / lowering control solenoid valve YV18A
18	Compensation control solenoid valve YV15A
19	Compensation control solenoid valve YV15B
20	LS control solenoid valve YV1
21	Turntable rotation left solenoid valve YV14B
22	Boom lifting PVG
23	Arm lifting PVG YV4
24	Proportional solenoid valve "On/Off" YV5
26	Driving solenoid valve YV6


E-Trouble shooting and diagram

Marking	Description
27	<ul style="list-style-type: none"> • Engine air filter clogging pressure switch B1 • Engine overheating pressure switch B2 • Engine oil pressure switch B3 • D+ and W
28	<ul style="list-style-type: none"> • Overload indicator HL13 • Buzzer HA2
29	Horn switch SB5
30	<ul style="list-style-type: none"> • Platform rotation switch SA4 • Platform leveling switch SA5 ; Turntable compensation selector SA17 • Platform jib switch SA7 • Platform box telescope switch SA9 • Platform overload SQ5 - SQ6
31	Turntable rotation right solenoid valve YV14A
34	Left platform rotation control solenoid valve YV19B
35	Right platform rotation control solenoid valve YV19A
39	5 ° tilt sensor SQ1
40	Hydraulic tank temperature probe B4
41	Retracted boom telescope sensor-Tilt reset contactor SQ3
42	Arm telescope retracted sensor-Tilt reset contactor SQ4
49	Fault indicator HL9
52	Horn HA1

E-Trouble shooting and diagram

3.1.5 - Diagnosis assistance indicators

Locations



Description of the components

Marking	Description
YV1	LS control solenoid valve
YV2	Boom telescoping PVG : • YV2a : Extension • YV2b : Retraction
YV3	Boom lifting PVG
YV4	Arm lifting PVG
YV5	Proportional solenoid valve for turntable rotation
YV6	Driving PVG
YV8	High-speed drive control solenoid valve
YV9	Differential locking control solenoid valve (Front axle)
YV10 - YV12 - YV17 YV23	Medium and high-speed drive control solenoid valve
YV11	Brake release control solenoid valve
YV13	High-speed drive control solenoid valve
YV14A	Turntable rotation right solenoid valve
YV14B	Turntable rotation left solenoid valve
YV15A	Compensation elevation control solenoid valve
YV15B	Compensation lowering control solenoid valve
YV18A	Jib lowering control solenoid valve
YV18B	Jib elevation control solenoid valve
YV19A	Left platform rotation control solenoid valve
YV19B	Right platform rotation control solenoid valve
YV21A	Reverse left-hand steering control solenoid valve
YV21B	Reverse right-hand steering control solenoid valve
YV22A	Front left-hand steering control solenoid valve
YV22B	Front right-hand steering control solenoid valve

E-Trouble shooting and diagram


3.1.6 - Buzzers

Description of the components

Marking	Description
HA1	Buzzer
HA2	Buzzer Platform control box : • Overload
HA4	Buzzer Ground control box : • Tilt sensor • Overload • Temperature • Driving buzzer option • Movement buzzer option

3.1.7 - Indicators

Locations




Description of the components

Marking	Description
HL1	Battery charging indicator
HL2	Air filter clogging indicator
HL3	Engine overheating indicator
HL4	Engine oil pressure light
HL5	Beacon light option
HL6	Spotlight option
HL7	Power ON indicator
HL8	On movement flashing light LED
HL9	Fault indicator
HL13	Overload indicator
HL30	Preheating indicator (Winter option)


E-Trouble shooting and diagram

3.2 - HYDRAULIC CIRCUIT

Refer to  Section E 4 - Hydraulic diagram

3.2.1 - Solenoid valves

Locations




Marking	Description
1	Proportional unit
2	Drive unit
3	Unit TOR
4	Steering unit

E-Trouble shooting and diagram


3.2.1.1 - Drive unit

Diagram extract



E-Trouble shooting and diagram

Drive manifold details




Marking	Description
1	Unit
2	Valve
3	Shuttle valve
4	Pressure relief valve
9	Flow divider
12	Plug
13	Flow divider
YV8	Switching to high-speed
YV9	Differential release
YV10	Medium and high-speed selector switch
YV11	Brake release
YV12	Medium and high-speed selector switch
YV13	Switching to high-speed
YV17	Medium and high-speed selector switch
YV23	Medium and high-speed selector switch

E-Trouble shooting and diagram


3.2.1.2 - Steering unit

Steering unit detail



Marking	Description
1	Unit
2	Plug
3	Shuttle valve
YV21	Solenoid valve
YV21A - YV21B	Coil
YV22	Solenoid valve
YV22A - YV22B	Coil
6	Valve

Diagram extract



E-Trouble shooting and diagram

3.2.1.3 - Unit TOR

TOR block details





Diagram extract




Marking	Description
A	Turntable rotation
B	Compensation
C	Jib arm
D	Platform rotation

E-Trouble shooting and diagram

3.2.1.4 - Proportional unit

Proportional unit detail



Marking	Description
1	Anti-impact relief valve
2	YV1 - LS control solenoid valve
3	Valve
4	Manual control
5	Distribution range
6	Slide
7	YV2 - Boom telescoping PVG : • YV2a : Extension • YV2b : Retraction
8	YV3 - Boom lifting PVG
9	YV4 - Arm lifting PVG
10	YV5 - Proportional solenoid valve for turntable rotation
11	: Driving YV6 - Driving PVG

E-Trouble shooting and diagram

Proportional unit





Diagram extract



E-Trouble shooting and diagram


Description of the components

Marking	Description
YV8	High-speed drive control solenoid valve
YV9	Differential locking control solenoid valve (Front axle)
YV10 - YV12 - YV17 YV23	Medium and high-speed drive control solenoid valve
YV11	Brake release control solenoid valve
YV13	High-speed drive control solenoid valve
YV14A	Turntable rotation right solenoid valve
YV14B	Turntable rotation left solenoid valve
YV15A	Compensation elevation control solenoid valve
YV15B	Compensation lowering control solenoid valve
YV18A	Jib lowering control solenoid valve
YV18B	Jib elevation control solenoid valve
YV19A	Left platform rotation control solenoid valve
YV19B	Right platform rotation control solenoid valve
YV21A	Reverse left-hand steering control solenoid valve
YV21B	Reverse right-hand steering control solenoid valve
YV22A	Front left-hand steering control solenoid valve
YV22B	Front right-hand steering control solenoid valve

E-Trouble shooting and diagram


4 - Electric diagram

Power - HA18PX - HA51JRT - E598J - folio 2




E-Trouble shooting and diagram

Station selection - HA18PX - HA51JRT - E598J - folio 3




E-Trouble shooting and diagram

ECU - 1/2 - HA18PX - HA51JRT - E598J - folio 4




E-Trouble shooting and diagram

ECU - 2/2 - HA18PX - HA51JRT - E598J - folio 5




E-Trouble shooting and diagram

Joysticks - HA18PX - HA51JRT - E598J - folio 6




E-Trouble shooting and diagram

Options - 1/4 - HA18PX - HA51JRT - E598J - folio 07




E-Trouble shooting and diagram

Options - 2/4 - HA18PX - HA51JRT - E598J - folio 08




E-Trouble shooting and diagram

Options - 3/4 - HA18PX - HA51JRT - E598J - folio 09



E-Trouble shooting and diagram

Options - 4/4 - HA18PX - HA51JRT - E598J - folio 10



E-Trouble shooting and diagram




Notes

E-Trouble shooting and diagram


5 - Hydraulic diagram

HA18PX - HA51JRT - 1/2



E-Trouble shooting and diagram

HA18PX - HA51JRT - 2/2



F-Records

1 - Intervention register

The intervention register keeps a record of maintenance and repair work carried out inside or outside the maintenance programme.

N.B.:--IN THE CASE OF A HAULOTTE SERVICES® INTERVENTION, THE QUALIFIED TECHNICIAN MUST INDICATE THE HAULOTTE SERVICES® INTERVENTION NUMBER.

Date	Type of intervention	Number of hours	Intervenor	HAULOTTE Services® intervention number

F-Records

Date	Type of intervention	Number of hours	Intervenor	HAULOTTE Services® intervention number

F-Records

Date	Type of intervention	Number of hours	Intervenor	HAULOTTE Services® intervention number

F-Records

Date	Type of intervention	Number of hours	Intervenor	HAULOTTE Services® intervention number

F-Records

Date	Type of intervention	Number of hours	Intervenor	HAULOTTE Services® intervention number

F-Records

Date	Type of intervention	Number of hours	Intervenor	HAULOTTE Services® intervention number